

經典

Kanenori

JAPANESE MOUNTAIN MACHETE WITH SHEATH

Single-edged blade C-30, C-31

INSTRUCTION

MADE IN JAPAN
〈日本製造〉

This product is ideal for cutting underbrush, felling trees, and pruning branches up in the mountains.

Before Use

We thank you very much for your purchase of this Machete. Please read this instruction carefully before starting of use.

Indication of basic mark

警告! Warning **禁止!** Prohibition **厳守!** Adherence

警告! To avoid an injury and product damage

- Don't touch it barehanded.
- Don't carry it having a blade part.
- Don't swing it around.
- Don't put it near fire.
- Keep it away from children.
- Do not use this product to cut metal.



● Please refrain from horizontally striking vertically rigid objects like bamboo. There is a danger the machete might snap back, causing injury or damage to the blade.



Preparations before the use

Before use, check that the blade is clean and the handle is not loose or broken.

Start of Using


This machete is ideal for splitting, cutting, and shaving down wood. Note failure to use this product properly can result in injury and/or damage to the product.

Basic Usage (It is designed for right-handed.)

(1) Cutting (Pruning, weeding, etc.)

When pruning, position yourself so that the branch you want to cut is jutting out from the left side of the tree trunk. If you try to cut a right-facing branch with a single-edged blade, there is a risk that its shape will cause the blade to become wedged in the tree trunk. (fig.1) To cut a right-facing branch, walk around the tree so that the branch now faces left and make your cut. When pruning, always cut away from your body. Always check to make sure you are not endangering those around you. (fig.2)

Name of part



(1) To avoid injury and damage of the machete, don't twist or pry it, don't cut forcibly, don't cut the metals.

Maintenance

- (1) After use, wipe off water and dirt stuck to blade and handle with cloth.
- (2) After cleaning, put anti-rust oil on the blade.



One-point advice

After use, please apply rust prevention oil or machine oil periodically to prevent rust.



Don't use thinner or benzine



Specifications

Name: Japanese mountain machete with sheath
 Model No. C-30, C-31
 Full length: 400mm Handle size: 155mm
 Blade size: 240mm Weight: 440g
 Application: For clearing underbrush and pruning small branches.
 Materials: Blade: Hitachi Yasugi Specialty Steel Shirogami No. 3
 Handle: Oak